

AT AC DISCONNECT SWITCH

**MAIN PV SYSTEM
AC DISCONNECT**

ON SERVICE/LOAD PANEL
(AC DISTRIBUTION PANEL)

 **WARNING** 
ELECTRICAL SHOCK HAZARD
DO NOT TOUCH TERMINALS.
TERMINALS ON BOTH LINE AND
LOAD SIDES MAY BE ENERGIZED
IN THE OPEN POSITION

WARNING - DUAL POWER SOURCE
SECOND SOURCE IS PV SYSTEM

PHOTOVOLTAIC AC DISCONNECT
MAXIMUM AC OPERATING CURRENT: **14.2A**
MAXIMUM AC OPERATING VOLTAGE: **240VAC**

WARNING
INVERTER OUTPUT CONNECTION
DO NOT RELOCATE THE
SOLAR BREAKER

CAUTION
PV SYSTEM CIRCUIT BREAKER IS BACKFED

 **WARNING:**
TURN OFF PHOTOVOLTAIC
AC DISCONNECT PRIOR TO
WORKING INSIDE PANEL

SIGNAGE			
DOLD RESIDENCE			
SOLAR ARRAY INSTALLATION		ENG: DOLD	
		DR: DOLD	DATE: 1/20/2014
		SCALE: NONE	
SUBSTANDARD CONSTRUCTION		SIZE	REV
		B	A
		SHEET: PG7	